


User Manual
smart gazebo
Product Code OFC195E-200


OPUS[®]
smart gazebo



YOUR ADVENTURE STARTS HERE

opustents.com

Find the most up to date version of this manual, set-up videos and more here!
opustents.com/start



CONTENTS


Package contents	2
Before you start	3
Climate groups	3
Elevation groups	3
Wind speeds	3
Warnings	3
Setting up your Smart Gazebo	4
Optional accessories set-up	5
Smart Tent LED lighting kit	5
AIR Windbreak Kit	5
Packing down your Smart Gazebo	5
Care & maintenance	6
Drying your Gazebo	6
Battery care	6
Condensation and moisture	6
UV protection	6
Climate variable AIR tube pressure	6
Seams	7
Spare parts	7
Repairs	7
Warranty	8

PACKAGE CONTENTS

When you first open your OPUS® Smart Gazebo, make sure that all the components that we list below are present in your package. You'll need each of these items in order to perform a speedy and reliable inflation.



- A. 1 x OPUS® self-inflating Smart Gazebo
- B. 1 x carry bag
- C. 1 x removable groundsheet
- D. 1 x OPUS® Blow Bank 3000mah battery
- E. 4 x heavy duty tent pegs
- F. 16 x lightweight tent pegs



BEFORE YOU START

We want to make sure that you get the very best out of your OPUS® Smart Gazebo, so here are some of the scenarios we've designed it for. We do not recommend using your OPUS® Smart Gazebo outside of these conditions – each of our products is devised for a specific use case, and may not be appropriate for every camping situation. Exercise caution when setting your OPUS® Smart Gazebo up in adverse conditions.

Climate groups

Temperate	Continental
Summer winter	Summer

Not suitable for tropical, dry and polar climate groups. Lowest recommended operating temperature – 0 °C
Highest recommended operating temperature – 28 °C

Elevation groups

- Coastal
- Inland
- Lowlands

Wind speeds

Up to strong breeze (25 – 31mph windspeed)

As the seasons change, so will the pressure inside your OPUS Smart Gazebo air tube system, with expansion and contraction to be expected depending on external temperatures. It is important to be aware of and monitor the air tubes to ensure the product functions as intended

Usability

Between 2 – 5 weeks camping per year.

To ensure a good lifetime for your Gazebo, we recommend to use it for no more than 5 weeks out of the year. To preserve the condition of your Gazebo, make sure to read and follow our set-up instructions carefully, as well as our care and maintenance instructions.

Warnings

Before setting up your Gazebo, you must familiarise yourself with all warning labels, documentation, and safety instructions on the shipping box, any documentation inside the shipping box, on the transport

bag, or on the Gazebo itself. We want you to feel fully confident setting up your Gazebo, so it's important that you spend some time going over the manual and any other information you've been provided.

Fire hazards

- Do NOT use a naked flame inside or near to your Gazebo.
- Do NOT use an open fire inside or near to your Gazebo.
- Do NOT smoke inside or near to your Gazebo.

Carbon monoxide hazards

- Carbon monoxide is an odourless, colourless gas, which is produced during burning of combustible products, it is HIGHLY TOXIC and can be FATAL.
- Do NOT use a gas stove inside your Gazebo.
- Do NOT use a barbecue or charcoal oven in your Gazebo.
- Do NOT leave a recently extinguished barbecue or fire-pit inside your Gazebo (recently extinguished fires can sometimes give off carbon monoxide, even if they aren't glowing or producing smoke).

Trip hazards

The guy-lines, storm-straps, or other components of the Gazebo may present a trip hazard, take care when walking around the perimeter of the Gazebo.

Battery usage

After inflation has been completed, ensure that you remove the Blow Bank Battery packs from the in-built pumps, this will avoid accidental inflation during pack down.

SETTING UP YOUR SMART GAZEBO

Is this your first time setting up an air inflated product? Well, relax – we've tried our best to write our instructions in plain and simple terms, so everyone can get outdoors the smart way. If you have any issues, we recommend watching our set-up tutorial video so you can follow along with every step and see how the experts do it!

watch set-up videos and more here!
opustents.com/start

1. Check your pitch.

Visually inspect your pitch – you want to make sure that the ground is as clear as possible.

2. Unfold and lay out your Gazebo, pegging the corners down with the lightweight pegs ensuring not to peg it out with too much tension.

The Gazebo doors should all be zipped closed before you start. Locate the 4 legs of the Gazebo and peg each one ensuring there's not too much tension.

3. Close all the external valves on the Gazebo.

Locate the Gazebo tubes housing the valves and unzip the protective cover. Ensure that the valves are screwed down tight enough to prevent air leakage, but not too tight that you can't get them back open again!

4. Inflate the Gazebo by performing the following steps:

- Install the Blow Bank Battery
- Press the inflation button,
- Zip closed the protective cover.

When the pump detects that it has reached the correct pressure, it will automatically switch off.

5. Unfold and peg out the multi-point storm straps.

There's 4 straps on the Gazebo, 1 on the outside of each corner. These straps will help provide tension and stability to the Gazebo.

6. Peg out the Gazebo doors as required.






Each door has 3 pegging points, 1 on each side and 1 in the centre.

7. As soon as the pump has finished inflating, unzip the cover, remove the battery from the pump, and zip the cover closed again. You can now bring the battery into the Gazebo.

8. Place the battery into the storage pocket on the AIR tube – you'll now be able to connect your lighting system or charge your mobile devices!

9. Install the removable groundsheet

Unfold the groundsheet and place within the Gazebo structure. Each edge has a male velcro strip, connect these to the female strip on the Gazebo floor skirt.




Congratulations! The set-up of your OPUS® Smart Gazebo is now complete.

OPTIONAL ACCESSORIES SET-UP

Smart Tent LED lighting kit (OPUST-006)

Once the sun sets, keeping the last laughs of the evening nicely lit is a top priority! The OPUS® Smart Tent LED lighting kit allows you to use your OPUS® Blow Bank Battery to power LED lighting strips inside the Gazebo, keeping your nights illuminated!

1. **Bring your OPUS® Blow Bank Battery inside the Gazebo and place it into the storage pocket inside the outer cover of the air tube. Plug one of the USB-C cables into the connector on the Blow Bank Battery and pull the USB cable through the eyelet in the battery storage pocket. Then trail the cable upwards along the length of the tube, zipping closed the cover behind it.**
2. **Unroll your lighting strip and, beginning with the female end (the socket and not the plug), zip the strip into the clear plastic sleeve that runs along the tube. Keep zipping the clear plastic sleeve as you run the cable until you reach the end of the cable.**
3. **The setup of your Smart Tent LED lighting kit is now complete!**



AIR Windbreak Kit (OFC195C-190)

The OPUS® windbreaks attach via an integrated zip located on the legs of the Smart Gazebo, this means that you can extend your layout on the pitch to include a sheltered area around the entrance to your Gazebo.

It is simply a case of inflating the AIR Windbreak Panels (hand pump included), zipping them onto your Smart Gazebo, pegging the base of the windbreak down and then pegging it out. If the weather is particularly blustery, you'll want to use the storm-straps too!



PACKING DOWN YOUR SMART GAZEBO

1. **Remove the battery from the storage pocket inside the air tube outer cover.**
2. **Withdraw the pegs from the ground, releasing the straps and fixing points. Open the grey valves, releasing the pressurised air and deflating the structure.**
3. **Remove the pegs at the four corners of the Gazebo.**
4. **Taking care to fold the material (towards the grey valves where possible) so that you encourage any remaining air to escape, you can now roll the main Gazebo up. You can now place the Gazebo back into the transport bag.**

CARE & MAINTENANCE

It's very important that you look after your OPUS® Smart Gazebo, like any camping product it's bound to be impacted by the elements. With the proper care and maintenance, you'll be able to enjoy your OPUS® Smart Gazebo for years to come.

Drying your Gazebo

After a wet day, you'll want to make sure that your Gazebo is fully dried before being packed away for storage for an extended period of time. Mildew can build up on wet surfaces, given enough time, so it's important to avoid a wet pack-down, where possible. However, sometimes you just can't avoid it – in which case, you'll want to make sure that you unpack and dry the Gazebo as soon as you return home. Ensure that both the inside and outside are dry (including behind the window blinds) before packing your Gazebo away.

Battery care

You should only charge your Blow Bank Batteries using the included charging hub. The LED indicator on the battery will be red (solid or flashing) while it is charging, and green when fully charged.

Batteries must be maintained when in storage. They should be stored between 30 - 60% capacity and re-charged every 2 months to ensure a prolonged life span.

Condensation and moisture

When you have a humid environment and a temperature gradient separated by a barrier membrane, condensation and the build-up of moisture is almost unavoidable. In order to increase material strength and waterproofing and to reduce weight, Gazebo canvases will often utilise a synthetic blend, which increases the chance of condensation forming. Overnight, when the temperature outside lowers, condensation is likely to form on the inside surface of the Gazebo – this is

due to the air humidity increasing through respiration during sleep. Sometimes, if the gradient between the inside and outside is extreme, this can even form water droplets or small puddles. This is perfectly normal, and a very common aspect of camping life.

There are steps to take to reduce your condensation build-up. Ventilation is key – creating a good flow of cool air coming into the Gazebo to replace the warm and humid air that escapes will help reduce moisture build-up. You can also choose to pitch your Gazebo away from water sources such as streams or ponds, and pitching on higher open ground will also help reduce condensation.

We recommend that, when you wake up in the morning to find that condensation has formed, simply wipe down the interior with a microfibre cloth.

UV protection

The Sun produces a large amount of ultraviolet radiation which damages whatever it shines onto, which is the reason that we need to wear sun-cream in the Summer! Similarly, the fabric of your Gazebo needs protecting from UV light, as over time it can damage the molecular makeup of the canvas. We recommend pitching your Gazebo in shaded areas, where possible, to avoid direct sunlight. Damage to your canvas caused by UV radiation is not covered under warranty, so make sure that you take steps to protect your Gazebo where possible.

Climate variable AIR tube pressure

As the seasons change, so will the pressure inside your OPUS Smart Gazebo air tube system, with expansion and contraction to be expected depending on external temperatures. It is important to be aware of and monitor the air tubes to ensure the product functions as intended.

Warmer climate groups

As external temperatures rise, the pressure in your air tube system will increase and this can lead to excess pressure in the air tube structure. In warmer climate groups it is advisable to release air from the system by partially unscrewing one of the grey air valves for a few seconds to reduce the pressure in your air tube system. Ensure the grey air valve is re-tightened after release.

Colder climate groups

As external temperatures lower overnight and in colder months, the pressure in your air tube system will decrease, which can result in the appearance of product deflation or less rigidity in the air tubes. It is therefore important to ensure the pressure in your air tube system is regularly checked and corrected if needed. Simply turn on the air inflation pump(s) to re-pressurise your air tube structure to the pre-set and required pressure.

Failure to do this could invalidate any warranty claim for damage to the air tubes or associated components.

Seams

In the event of a tear or rip in your main canvas, it is important that you use an appropriate seam sealer to seal any new

stitch holes after repair. By expanding into and sealing the stitch holes made in the process of a repair, the proper application of seam sealant will prevent water ingress.

Spare parts

If you are looking to purchase additional batteries or optional items you can find supplying stockists on our website - www.opustents.com/stockists/.

If you require spare parts please contact your supplying stockist or contact OPUS® directly by phone on +44 (0) 1473 601200 or email - inflate@opustents.com

Repairs

The air tube used in the OPUS Smart Gazebo is fused - meaning both bladders are fused together and no internal isolation valves are required. This means the Gazebo will need to be fully deflated to conduct any repairs.

WARRANTY

We recommend registering your new OPUS® product – to do so please head to our website and register as soon as possible after purchase date. By registering your product and providing your contact details we can keep you in touch with user updates, optional items, and future developments.



<https://www.purpleline.co.uk/product-registration/>

A valid proof of purchase is required to initiate any warranty claim – please ensure you keep your proof of purchase (physical retailer receipt, order confirmation email or invoice).

NB: Please carefully inspect your purchase immediately after delivery. Claims for missing or damaged items must be reported to your supplying retailer within 7 days of receipt. Claims for missing or damaged items reported beyond this period cannot be considered as a warranty claim.

OPUS® strives to provide you with a product that is of the very highest quality. If, however, you believe that a component has failed prematurely under normal working conditions, you may wish to report this to your supplier in the first instance for immediate support and guidance. Alternatively, the scope of your product warranty is listed below for your information.

The pursuance of claims may require the following:

- The claimant is the original owner (the warranty is not transferable).
- The warranty has not expired
- We will request images/videos and detailed information to highlight the issue for all warranty claims.
- We may request the item to be returned to the supplying retailer or OPUS® for physical inspection to uphold the claim. (OPUS® will refund the postage cost for returning and reissuing repaired/replacement goods if the issue is deemed a valid warrantable claim. If the claim is not valid the consumer is responsible for all postage costs.
- Products returned for inspection to the supplying retailer or OPUS® (after request) must be clean and dry. Any products received in an unsatisfactory condition to allow inspection may be returned to the sender without inspection. All postage costs are payable by the consumer if products are received in an unsatisfactory condition.

The following is offered as a helpful guide to determine the scope of the warranty. Only valid claims for inherent defects in components or workmanship, or premature component failure under normal operating conditions will be upheld, and within

FABRIC Included all associated fixings related (but not limited to) Flysheet, Removable Groundsheet, Doors, and Air Bladder Sleeves.	
What's covered?	
	Zip failure due to a manufacturing defect.
	Missing or loose fixing points such as: guy lines, pegging points, toggles and zips.
	Tears, plucks or holes in the material from new.

FABRIC Included all associated fixings related (but not limited to) Flysheet, Removable Groundsheet, Doors, and Air Bladder Sleeves.	
What's excluded?	
	Damage during setup or pack down including but not limited to ripped fabric and holes.
	Damage caused by pegs, poles and other ancillary items that have not been stored in the appropriate supplied bags.
	General wear and tear and/or neglect and/or misuse, or modifications.
	Damage caused by wet pack down including (but not limited to) colour transfer and mould.
	Damaged caused by sharp objects e.g. puncturing the material.
	Damage caused by including (but not limited to) UV colour fading, PVC deterioration, nicotine damage, fire and smoke damage, extreme weather/environmental conditions, and natural degradation.
	Slubs (thread runs) in the fabric which are a natural characteristic.
	Damage caused by abuse, misuse or failure to follow instructions relating to (but not limited to) inflation/erection, dismantling, storage, cleaning, pack down/rolling of the doorways etc.
	Water ingress and moisture caused by (but not limited to) condensation (see page 11) or leakage caused by excessive abrasion.
	Leakage through seams including main seams where it has not been possible to tape/apply seam sealing during the manufacturing process or where tape has peeled away or where tape is broken as part of the manufacturing process because of the necessity to incorporate tie points, suspension points etc.
	Broken and/or damage to zips caused by (but not limited to) undue force, incorrect pegging and jamming.
	Damage due to over/under tensioning and/or inflation including (but not limited to) damaged seams, zips, pegging points etc.
	Excessive usage not classed as leisure, such as permanently erected at a private residence for a period beyond typical leisure use (see page 5 for usability).

AIR SYSTEM Air Bladders, Air Valves and fittings.	
What's covered?	

AIR SYSTEM Air Bladders, Air Valves and fittings.	
	<ul style="list-style-type: none"> · Manufacturing defects relating to (but not limited to): <ul style="list-style-type: none"> - Ballooning of air bladder caused by zip failure - Blow Bank Pump failure - Cracked vales or fittings - Air leakage
What's excluded?	
	General wear and tear and/or neglect and/or misuse, excessive force or any modifications.
	Prior repairs conducted independently outside of the provided repair kit/prior approved repairs.
	Punctures from sharp objects.
	Over/under inflation.
	Valves crushed/damaged during operation, pack down, transit or incorrect storage.
	Damage caused by using non-supplied or approved pumps for inflation (OPUS® Hand Pump or Blow Bank pumps fitted).
ELECTRICAL SYSTEM Batteries, pumps, charging hub and cables.	
What's included?	
	Component has failed on arrival or during first inspection (within 7 days of ownership).
What's excluded?	
	General wear and tear and/or neglect and/or misuse, excessive force or any modifications.
	Water damage to any component
	Improper storage and use
	Reduction in battery capacity over time
MISCELLANEOUS ITEMS (such as but not limited to) Storage Bag, Ex-Display Gazebos, 3rd Party Products etc.	
What's covered?	
	Manufacturing or component defect leading to premature failure under normal usage/conditions (see page 5 for usability).
What's excluded?	
	Product used for hire, ex-display, permanent (or semi) pitched and general commercial use beyond typical leisure use (see page 5 for usability).

MISCELLANEOUS ITEMS (such as but not limited to) Storage Bag, Ex-Display Gazebos, 3rd Party Products etc.	
	Damage to Storage Bag and component storage bags including (but not limited too) rips, tears, zip and handle failure.
	Consequential or other damages, losses or expenses in connection with or by reason of inability to use the product for any purpose.
	Damage to 3rd party products charged via Blow Bank batteries such as (but not limited to) non-OPUS® LED Lighting, mobile phones, tablets and all other electrical devices.

PLEASE NOTE THAT YOUR STATUTORY RIGHTS ARE NOT AFFECTED BY THE TERMS AND CONDITIONS OF THIS PRODUCT WARRANTY

The Manufacturer and/or their recognised agents, directors, employees, or insurers will not be liable for consequential or other damages, losses, or expenses in connection with or by reason of the inability to use the product for any purpose.

The manufacturer holds no liability for any issues relating to missing components, defective products, or non-functioning items on arrival (classified as 'dead on arrival') unless the issue has been reported within 7 days (from delivery date/collection date from retailer) of initial ownership and prior to first use.

In the event of a product being returned for assessment, it must be sent in a completely dry and clean condition. Including suitable packaging to prevent any damage during transit. Failure to do this may affect your claim.

The warrantable goods remain the responsibility of the customer until they have been received by the retailer/manufacturer to conduct the warranty assessment.

The warranty is valid for two years on all components excluding pumps, batteries and other electronic components, which are subjected to a one-year warranty from the date of purchase.

General & Warranty Enquiries:

inflate@opustents.com

+44 (0)1473 601200

**Purple Line Limited T/A OPUS®,
Unit 1, Peninsula Business Centre**

Wherstead, Suffolk


IP9 2BB

UK

OPUS® Terms & Conditions and Warranty information can be found online at:
www.opustents.com

Manual revision 1 - May 2025

OPUS[®]
smart gazebo



OPUS[®] Smart Gazebo

Purple Line Limited. Peninsula Business
Centre, Wherstead, Suffolk, IP9 2BB. UK.

01473 601200 - opustents.com

Patents protected

www.our-patents.info/purpleline